
# 2,2,4-TRIMETHYL PENTANE



## 1. PERFORMANCE

1) Measuring range  $\begin{array}{c} \text{Number of pump strokes} \\ \text{Nsampling time} \end{array} \begin{array}{c} \text{: } 200\text{-}4,000 \text{ ppm} \\ 1/2 \left(50 \text{m} \ell \right) \\ \text{: } 1.5 \text{ minutes/1 pump stroke} \\ \end{array}$ 

3) Detectable limit : -4) Shelf life : 2 years
5) Operating temperature :  $15 \sim 25 \,^{\circ}$ C

6) Reading : Graduations printed on the tube are calibrated by n-Hexane at 1 pump stroke and 2, 2, 4-Trimethyl Pentane concentration is determined by using a conversion

chart at 1/2 and 1 pump strokes.

7) Colour change : Orange → Yellowish green

#### 2. RELATIVE STANDARD DEVIATION

RSD-low: 10% RSD-mid.: 10% RSD-high: 5%

# 3. CHEMICAL REACTION

Chromium oxide is reduced  $CH_3 (CH_2)_5 CH_3 + Cr^{6+} + H_2 SO_4 \rightarrow Cr^{3+}$ 

# 4. CALIBRATION OF THE TUBE


GAS CHROMATOGRAPHY

(for 1 pump stroke) 2, 2, 4-Trimethyl Pentane concentration (ppm)



No.113SB Tube reading (ppm)

(for 1/2 pump strokes) 2, 2, 4-Trimethyl Pentane concentration (ppm)



No.113SB Tube reading (ppm)